
	<b>Standard Operating Procedure</b>	Department	Quality Assurance
	<b>Licenses Activation at Installation</b>	Owner	Greg Wieckowski
Document No.		QC07-C	
Issue No.		4	
Date:		20/07/2018	
		Page	1 of 3

## Content of the USB flash drive:

- **Licence\_IMOS.ini** (*DS200i/DS600i/DATACARD/CARDFOLDER*)
- **license.alf** (*AIMS - 100 Onboard*)
- **MainCfg.ini** (*system configuration*)
- **IMOS software installation file**
- **User guide**

Turn the page to see step-by-step procedure of activation the licenses

	<b>Standard Operating Procedure</b>	Department	Quality Assurance
	<b>Licenses Activation at Installation</b>	Owner	Greg Wiekowski
		Document No.	QC07-C
		Issue No.	4
		Date:	20/07/2018
		Page	2 of 3




1. Collect USB flash drive from the Head Inserter box and plug into IMOS PC.



2. System configuration and reading licensing.




Copy **MainCfg.ini** and **Licence\_IMOS.ini** from USB flash drive to below directory. When ask, confirm to replace file.

- DS200I / DS600i            C:\ProgramData\Neopost\DS600 IMOS\
- DATACARD                    C:\ProgramData\Neopost\DS244HD IMOS\
- CARDFOLDER                C:\ProgramData\Neopost\DS244HD CardFolder IMOS\




3. AIMS – 100 OnBoard licensing.

Copy **licence.alf** from USB flash drive to C:\Program Files (x86)\AIMS\Services\. Confirm to replace files.



*Note: After copying licence.alf, IMOS PC require rebooting to activate licence on AIMS.*

	<b>Standard Operating Procedure</b>	Department	Quality Assurance
		Owner	Greg Wieckowski
<b>Licenses Activation at Installation</b>	Document No.	QC07-C	
	Issue No.	4	
	Date:	20/07/2018	
	Page	3 of 3	

4. Remove USB flash drive and keep in safe location as a backup. The USB flash drive can be used in case of replacing PC or hard drive or re-installing IMOS software in the future.

End of procedure